


POWERLINE®

MODEL 901 By Daisy
MULTI-PUMP PNEUMATIC AIR RIFLE



HIGH VELOCITY OVER 300 FPS
16+
For Ages 16 And Older
With Adult Supervision.

.177 Cal. (4.5 mm) Steel Air Gun Shot
.177 Cal. (4.5mm) Lead Airgun Pellet

WARNING: NOT A TOY. ADULT SUPERVISION REQUIRED. MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY OR DEATH. MAY BE DANGEROUS UP TO 291 YARDS (266 METERS).
THIS IS A HIGH POWER AIR GUN RECOMMENDED FOR USE BY THOSE 16 YEARS OF AGE OR OLDER. READ ALL INSTRUCTIONS BEFORE USING. THE PURCHASER AND USER SHOULD CONFORM TO ALL LAWS GOVERNING USE AND OWNERSHIP OF AIR GUNS.

⚠ WARNING: THIS GUN CAN CAUSE DEATH. READ AND FOLLOW THE INSTRUCTIONS CAREFULLY. DO NOT LOAD A BB OR PELLET INTO THE CHAMBER UNTIL YOU ARE READY TO SHOOT. IF YOU DO LOAD A BB OR PELLET AND DECIDE NOT TO SHOOT, REMOVE EITHER MANUALLY OR BY SHOOTING IT IN A SAFE DIRECTION, AN UNCOCKED, UNLOADED GUN IS SAFEST. ACCIDENTS HAPPEN FAST, AND ACCIDENTALLY INJURING OR KILLING SOMEONE IS A TERRIBLE THING. SHOOT SAFELY.


⚠ This safety alert symbol indicates important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

The "Introducing PowerLine® Shooting" section of this book, which starts on page 9, tells about the rules of shooting safety. **READ THIS SECTION.** Follow the safety rules and make certain anyone using your gun has been instructed in proper gun handling and safety.

This air gun shoots with up to ten times as much muzzle energy as the traditional spring air BB gun. More power means greater chance of serious injury or death. **BE SURE TO READ THE RULES FOR PROPER GUN HANDLING ON PAGE 10.**

Although your new PowerLine® Air Rifle is not a firearm, it has lethal potential and should be treated with the caution and respect due any conventional firearm. Like a firearm, your PowerLine® Air Rifle, when misused or carelessly used, can kill or seriously injure the shooter or other persons. Always remember, the first and most important safety aspect of any gun is the shooter. All safeties are mechanical devices and the shooter is the only part of the system that can make a gun safe—or unsafe. **DON'T DEPEND ON MECHANICAL SAFETIES;** think ahead and avoid situations that might lead to accidents.

Guns differ in their operation and you are never ready to fire any gun until you are thoroughly familiar with it. Read the following operating instructions and **WITHOUT LOADING A PROJECTILE,** proceed several times through the operating steps with your gun (dry fire the gun at a safe target) so that you will be able to operate the PowerLine® 901 properly and safely.



HOW TO OPERATE:

⚠ CAUTION: Be sure gun is always pointed in a safe direction

Step 1. OPEN BOLT

Step 2. PUT "ON" TRIGGER SAFETY ("PUSH SAFE")

Step 3. PUMP

Step 4. LOAD



Step 1. OPEN BOLT

Pull straight back on bolt handle, pulling it fully to the rear (Figure 2). The gun cannot fire with bolt open.

Step 2. PUT "ON" TRIGGER SAFETY ("PUSH SAFE")

The bolt must **FIRST** be opened, then the trigger safety is pushed from the left to right so that **NO** red is showing (See Figure 3) ("PUSH SAFE").

⚠ CAUTION: Gun must always be pointed in a safe direction.




Step 3. PUMP

The bolt should be opened when pumping the gun. For greater safety, we recommend that the bolt remain open while pumping and that you close the bolt only when the barrel can be pointed in a safe direction. With the muzzle pointed in a safe direction, pump the gun the desired number of times up to 10. More power means greater chance of serious injury. Never put finger on trigger until ready to fire the gun. **NOTE:** Do not pump your gun more than 10 times. Muzzle energy increases produced by more than 10 pumps are minor, and increased pumping may damage your gun.

⚠ CAUTION: Be sure to grasp forearm firmly as you close it to prevent it from snapping back and causing possible injury. Also be careful to keep fingers out of cocking mechanism when closing forearm. (See "PINCH POINTS," Figure 4)

⚠ WARNING: Do not open the bolt, close the bolt and then pull the trigger before pumping. This procedure can result in a loaded gun and a projectile being expelled from the gun during pumping. Recock the gun by opening the bolt and put "ON" trigger safety before pumping as in Steps 1 and 2.



We recommend the following number of pumps for different shooting conditions.


- For indoor shooting, 2 pumps
- For 10-meter (33-ft.) distance, 4 to 6 pumps.
- For longer distances, 7 to 10 pumps.

NOTE: Do not pump more than 10 times. Over pumping may cause serious damage to the gun.

	MAXIMUM VELOCITY (10 PUMPS)	MUZZLE ENERGY (10 PUMPS)	SHOOTING DISTANCE (10 PUMPS)
BBS	750 fps - 229 mps	5.6 ft. lb. - 7.6 J	291 yds. - 266 m
PELLETS	715 fps - 218 mps	7.6 ft. lb. - 10.3 J	284 yds. - 259 m

Step 4. LOAD FILLING THE BB MAGAZINE:

The loading door is located on the left side of the receiver (Figure 5). Push the door down and tilt gun with muzzle end down. Fill magazine with approximately 50 BBS. Do not overfill or the feed system may not operate properly.






LOADING BBS: With the bolt handle back and BBS in the magazine (See "FILLING THE BB MAGAZINE" above), RAISE the muzzle of the gun 45 degrees to 90 degrees. When raising the muzzle, be sure the front sight is pointed upward since the gun may not feed properly if it is on its side (Figure 6). A BB can be seen on the magnetic tip by looking into the loading port (Figure 7). If a BB does not feed onto the magnetic tip when the muzzle is raised, shake the gun slightly until you see a BB in the loading port. Push bolt handle fully forward and the BB is in firing position.

CAUTION: Always view the BB or Pellet when closing the bolt and loading port.

WARNING: BBS feed from the magazine by gravity which requires that the muzzle be raised. **NEVER ASSUME THE MAGAZINE OR CHAMBER IS EMPTY** even if the gun does not fire a projectile one or more times.

LOADING PELLETS: With the bolt back and BBS removed from the magazine (See "TO EMPTY MAGAZINE," Page 6), advance the bolt forward until the magnetic tip is visibly even with the rear edge of the pellet loading port; lower the muzzle and load a pellet, solid end forward (Figure 8). Push the bolt handle fully forward and the pellet is chambered in the firing position.



IMPORTANT: Do not allow a pellet to fall into the rear of the loading port and become jammed in the BB feed hole. If this occurs, have a qualified gunsmith remove the left receiver and clear the loading port or return gun to Daisy.

IMPORTANT: Care must be exercised when shooting pellets while the magazine contains BBS. Loading a BB and pellet at the same time may result in a jammed or obstructed barrel.


Step 5. CLOSE BOLT

Close bolt by pushing fully forward on bolt handle to chamber either a BB or pellet and lock the bolt.

CAUTION: The gun is now loaded and ready to fire.

Step 6. AIM AT SAFE TARGET

Aim the gun at a safe target. To be a consistent marksman, use the correct sight picture each time you fire your gun (Figure 9). **Never point a gun, loaded or unloaded, at anyone.**



CAUTION: Due to the power of this air gun, use extra caution in selecting a safe target backdrop. This gun should not be used with BB gun target backstops. Pick targets that cannot be penetrated or that will not cause ricochet because of their hard surface. Use only targets and traps that are designed for use with high power air guns. Do not shoot at water.

Step 7. TAKE "OFF" TRIGGER SAFETY ("PUSH FIRE")

When you are certain the target, backdrop and surrounding area is safe, take trigger safety "OFF" by pushing from right to left so that red is exposed (See Figure 3) ("PUSH FIRE"). Your gun is now cocked and ready to shoot. In this condition, it should be handled with extreme care.

Step 8. FIRE

After making sure the gun is pointed in a safe direction, gently (but firmly) squeeze the trigger. Repeat Steps 1 through 8 to continue shooting, using the appropriate loading procedure. **NOTE:** To fire, bolt must be completely closed as indicated in Step 5.

CAUTION: Do not leave your gun pumped for an extended period of time. Leaving your gun pumped for more than one hour could result in permanent damage to the air release valve.

WARNING: If a BB or pellet does not fire after completing the operation steps, the gun is jammed. This is a dangerous condition.

Open the bolt and put "ON" trigger safety immediately. If the bolt is not completely closed, do not try to close it until after opening it by pulling the bolt handle all the way back. The gun will not fire a projectile when the bolt is completely open.

Repeat all operations except Step 4 (do not load BB or pellet), pumping gun 10 times. If a projectile still does not fire, follow these steps carefully:

1. Open bolt.
2. Put trigger safety "ON".
3. Clear barrel by running a cleaning rod through from the muzzle end. Be careful not to damage the bolt tip by pushing the rod through too hard. Do not reuse this BB or pellet.
4. Repeat operation steps. Make sure a BB or pellet is fed into firing position. If after following the firing procedure the projectile is not fired, return your gun to Daisy (See "REPAIR OF DAISY GUNS" section).

UNLOAD PELLETS

The magnetic tip does not extract a pellet. You must shoot the pellet out if a safe target is available. If a safe target is not available, open bolt, put trigger safety "ON", insert a cleaning rod in the muzzle end and push the pellet out of the barrel. Do not allow a pellet to fall into the rear of the loading port and become jammed in the BB feed hole.

TO EMPTY MAGAZINE

Open bolt and put trigger safety "ON". Open the BB magazine door, cup your hand over it and tilt the gun fully to the left side. Shake gun until all BBs are removed. Then remove BB from loading port (Figure 7). To make certain no BBs remain, raise muzzle, shake well and work bolt forward and all the way back several times, removing any BBs that appear.

⚠ WARNING: Never assume gun is empty of projectiles. Always point the gun in a safe direction.

REAR SIGHT ADJUSTMENT

Your air gun is equipped with an adjustable rear sight.

HOW TO ADJUST SIGHT RIGHT OR LEFT (WINDAGE): Loosen screw "A" by turning counterclockwise (Figure 10). Move rear sight to the right side of the gun to make it shoot to the right, or to the left side of the gun to make the gun shoot to the left. Make certain screw "A" is retightened after adjustment.

HOW TO ADJUST SIGHT UP OR DOWN (ELEVATION): Raise the rear sight by moving sight elevator back to make the gun shoot higher. Lower the rear sight by moving the sight elevator forward to make the gun shoot lower (Figure 11).




Fig. 10




Fig. 11

PROPER CARE

To maintain top shooting performance, lightly oil the three pumping lever hinges and the foam wiper on the piston every 1,000 shots (Figure 12). Use a 10-, 20- or 30-weight non-detergent, automotive motor oil. **DO NOT** use light, household type oils or aerosol type spray lubricants since they may contain substances or additives harmful to the rubber seals or other components. Clean the exterior by wiping with a soft, clean, lightly oiled cloth. The screws are a gun blue finish. Wipe with oil to prevent rust.




Fig. 12

6

⚠ CAUTION: Improper lubricants, such as aerosol type spray lubricants, can ignite (diesel) during pumping. Use only automotive motor oils.

STORAGE

Before putting the gun away in a cabinet or gun rack, shoot the gun at a safe target to make sure the pump system and barrel are empty. Then, open the bolt and place the trigger safety "ON" ("PUSH SAFE"), then close the bolt. Always make sure the gun is empty and the trigger safety is "ON" ("PUSH SAFE") before storage. The gun should also be clean, dry and oiled. Store projectiles in a separate location from the gun to keep them away from untrained shooters.

MODIFICATION

⚠ WARNING: The components of this gun were engineered to deliver optimum performance. Any modification or tampering with a gun may cause a malfunction and may make it unsafe to use. Any change in performance, such as a lowered trigger force and shortened trigger travel, indicates possible wear and such gun should be inspected, replaced or properly repaired by qualified personnel. Any gun that has been dropped should be checked by qualified personnel to insure that its function has not been effected.

⚠ WARNING: A GUN THAT IS NOT OPERATING PROPERLY MAY BE DANGEROUS. IT SHOULD BE KEPT SAFELY FROM USE BY ANYONE UNTIL REPAIRED OR DESTROYED. DO NOT TRY TO TAKE THE GUN APART. IT IS DIFFICULT TO REASSEMBLE, AND IMPROPER REASSEMBLY CAN CAUSE A HAZARDOUS CONDITION.

GUNS IN WARRANTY

LIMITED ONE — YEAR WARRANTY

For one year from date of purchase, Daisy will repair or replace and return this gun, free of charge, if defective in material or workmanship. Service is available by returning the gun to Daisy Outdoor Products (refer to important note below). Attach to the gun, your name, address and telephone number, description of problem and proof of date of retail purchase (sales slip). Package and send transportation prepaid to Daisy. This Warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

IMPORTANT: You can return your inoperative rifle to Daisy for repair via United Parcel Service. Be sure to put "ON" safety and unload all ammo before returning the gun to Daisy. You must include your street address and phone number for Daisy to send your rifle directly back to you through UPS delivery.

GUNS OUT OF WARRANTY

If your PowerLine® gun needs repair, please call 1-800-713-2479 for repair charges. Daisy will repair the gun or replace it with a reconditioned gun of the same model if available. Otherwise, it will be replaced with a model of equivalent quality.

Daisy® Outdoor Products, Service Department, 11823 Lime Kiln Rd., Neosho, MO 64850 U.S.A.

7

MODEL 901 SPECIFICATIONS

ACTION	Multi-pump pneumatic; bolt action
CALIBER	.177 cal. (4.5 mm) BB or pellet
AMMO CAPACITY	50-shot BB; single-shot pellet
MAXIMUM VELOCITY*	750 fps BB *, 715 fps pellet*
OVERALL LENGTH	37.8 in. (95.9 cm)
WEIGHT	3.6 lbs. (1.63 kg)
MAXIMUM SHOOTING DISTANCE†	291 yds. (266 m)†
BARREL	20.8 in. (53 cm) Rifled steel
SAFETY	Manual cross bolt trigger block with red indicator

* Indicates 10 pumps
† Indicates 10 pumps with muzzle pointed upward at optimum angle